

Repair Parts for B&R HMI

Power Panel T30

Model	Offer Repair Spare Part	Delivery Conditions	Service
6PPT30.101N-20B	LCD,	New & Replacement	Available
6PPT30.101N-20W	Shell,		
6PPT30.101G-20B	Touch Glass		
6PPT30.101G-20W			
6PPT30.070M-20B			
6PPT30.070M-20W			
6PPT30.0702-20B			
6PPT30.0702-20W			
6PPT30.057L-20B			
6PPT30.057L-20W			
6PPT30.0573-20B			
6PPT30.0573-20W			
6PPT30.043K-20B			
6PPT30.043K-20W			
6PPT30.043F-20B			
6PPT30.043F-20W			
6PPT30.101G-20F			
6PPT30.0702-20F015			
6PPT30.043F-20C001			

Power Panel T50

6PPT50.101E-10A	LCD,	New & Replacement	Available
-----------------	------	-------------------	-----------

Repair Parts for B&R HMI

6PPT50.101E-10B	Shell, Touch Glass		
6PPT50.0702-16A			
6PPT50.0702-16B			
6PPT50.0702-10A			
6PPT50.0702-10B			
6PPT50.0502-16A			
6PPT50.0502-16B			
6PPT50.0502-10A			
6PPT50.0502-10B			

Power Panel C30

4PPC30.101G-23B	LCD, Shell, Touch Glass	New & Replacement	Available
4PPC30.101G-21B			
4PPC30.101G-22B			
4PPC30.0702-22B			
4PPC30.0702-23B			
4PPC30.043F-22B			
4PPC30.043F-23B			
4PPC30.043F-21B			
4PPC30.0702-21B			

Power Panel C70

4PPC70.0702-22F003	LCD, Shell, Touch Glass	New & Replacement	Available
4PPC70.0702-20F-007			
4PPC70.0702-20F003			

Repair Parts for B&R HMI

4PPC70.101N-23B

4PPC70.101N-23W

4PPC70.101N-22B

4PPC70.101N-22W

4PPC70.101N-21B

4PPC70.101N-21W

4PPC70.101N-20B

4PPC70.101N-20W

4PPC70.101G-23B

4PPC70.101G-23W

4PPC70.101G-22B

4PPC70.101G-22W

4PPC70.101G-21B

4PPC70.101G-21W

4PPC70.101G-20B

4PPC70.101G-20W

4PPC70.070M-23B

4PPC70.070M-23W

4PPC70.070M-22B

4PPC70.070M-22W

4PPC70.070M-21B

4PPC70.070M-21W

4PPC70.070M-20B

Repair Parts for B&R HMI

4PPC70.070M-20W

4PPC70.0702-23B

4PPC70.0702-23W

4PPC70.0702-22B

4PPC70.0702-22W

4PPC70.0702-21B

4PPC70.0702-21W

4PPC70.0702-20B

4PPC70.0702-20W

4PPC70.057L-23B

4PPC70.057L-23W

4PPC70.057L-22B

4PPC70.057L-22W

4PPC70.057L-21B

4PPC70.057L-21W

4PPC70.057L-20B

4PPC70.057L-20W

4PPC70.0573-23B

4PPC70.0573-23W

4PPC70.0573-22B

4PPC70.0573-22W

4PPC70.0573-21B

4PPC70.0573-21W

Repair Parts for B&R HMI

4PPC70.0573-20B			
4PPC70.0573-20W			
Power Panel PP15			
4PP015.0420-01	LCD,	New & Replacement	Available
4PP015.0420-36	Shell,		
4PP015.C420-01	Touch Glass		
4PP015.C420-36			
4PP015.E420-01			
4PP015.E420-101			
4PP015.E420-36			
4PP015.E420-K04			
4PP015.E420-K05			
4PP015.E420-K10			
Power Panel PP21			
4P0420.00-490	LCD,	New & Replacement	Available
4P0420.00-K08	Shell,		
4P0420.00-K11	Touch Glass		
Power Panel PP35			
4PP035.0300-01	LCD,	New & Replacement	Available
4PP035.0300-36	Shell,		
4PP035.0300-K08	Touch Glass		
4PP035.0300-K12			

Repair Parts for B&R HMI

4PP035.E300-01			
4PP035.E300-136			
4PP035.E300-36			
4PP035.E300-K05			
4PP035.E300-K10			
Power Panel PP41			
4P3040.00-490	LCD,	New & Replacement	Available
4P3040.00-K12	Shell,		
4P3040.00-K21	Touch Glass		
4P3040.00-K32			
4P3040.00-K43			
4P3040.00-K47			
4P3040.00-K50			
4P3040.01-490			
4P3040.01-K16			
Power Panel PP45			
4PP045.0571-042	LCD,	New & Replacement	Available
4PP045.0571-062	Shell,		
4PP045.0571-K01	Touch Glass		
4PP045.0571-K03			
4PP045.0571-K23			
4PP045.0571-K24			

Repair Parts for B&R HMI

4PP045.0571-K26			
4PP045.0571-K30			
4PP045.0571-K32			
4PP045.0571-K37			
4PP045.0571-K40			
4PP045.0571-K42			
4PP045.0571-K43			
4PP045.0571-K47			
4PP045.0571-K52			
4PP045.0571-K55			
4PP045.0571-K56			
4PP045.0571-L42			
4PP045.0571-X74			
Power Panel PP65			
4PP065.0351-P74	LCD,	New & Replacement	Available
4PP065.0351-X74	Shell,		
4PP065.0351-K01	Touch Glass		
4PP065.0571-K01			
4PP065.0571-P74			
4PP065.0571-X74			
4PP065.0571-P4			
4PP065.0571-K28			
4PP065.0571-K58			

Repair Parts for B&R HMI

4PP065.0571-K02			
4PP065.0571-K03			
4PP065.0571-K04			
4PP065.0571-K05			
4PP065.0571-K06			
4PP065.0571-K51			
4PP065.0571-K52			
4PP065.0573-K01			
4PP065.0571-P74F			
4PP065.0571-X74F			
4PP065.0571-B00			
4PP065.0571-K37			
4PP065.0653-K01			
4PP065.0702-K01			
4PP065.1043-K01			
4PP065.1043-K03			

Power Panel 100

4PP120.0571-01	LCD,	New & Replacement	Available
4PP120.0571-21	Shell,		
4PP120.0571-A5	Touch Glass		
4PP120.0571-K01			
4PP120.0571-K03			
4PP120.0571-K07			

Repair Parts for B&R HMI

4PP151.0571-01

4PP151.0571-21

4PP152.0571-01

4PP152.0571-21

4PP120.0653-K01

4PP120.1043-31

4PP120.1043-K05

4PP120.1043-K06

4PP151.1043-31

4PP152.1043-31

4PP180.1043-31

4PP181.1043-31

4PP182.1043-31

4PP120.1505-31

4PP151.1505-31

4PP180.1505-31

4PP181.1505-31

5PP120.0571-27

5PP120.0571-K06

5PP120.1043-37

5PP120.1043-37A

5PP120.1043-K03

5PP120.1043-K04

Repair Parts for B&R HMI

5PP120.1043-K08			
5PP120.1043-K09			
5PP120.1214-37			
5PP120.1214-37A			
5PP120.1505-37			
5PP120.1505-37A			
Power Panel 200			
4PP220.0571-45	LCD,	New & Replacement	Available
4PP220.0571-65	Shell,		
4PP220.0571-85	Touch Glass		
4PP220.0571-A5			
4PP220.0571-L65			
4PP220.0571-K04			
4PP220.0571-K05			
4PP220.0571-K06			
4PP220.0571-K15			
4PP220.0571-K16			
4PP220.0571-K22			
4PP220.0571-K23			
4PP220.0571-K33			
4PP250.0571-K03			
4PP250.0571-K09			
4PP251.0571-45			

Repair Parts for B&R HMI

4PP251.0571-65

4PP251.0571-85

4PP251.0571-A5

4PP251.0571-K01

4PP252.0571-45

4PP252.0571-65

4PP252.0571-85

4PP252.0571-A5

4PP220.1043-75

4PP220.1043-B5

4PP220.1043-K02

4PP220.1043-K03

4PP220.1043-K05

4PP220.1043-K08

4PP220.1043-K13

4PP220.1043-K14

4PP220.1043-K15

4PP220.1043-K16

4PP220.1043-K17

4PP220.1043-K19

4PP220.1043-75

4PP220.1043-V2

4PP251.1043-75

Repair Parts for B&R HMI

4PP251.1043-B5			
4PP252.1043-75			
4PP252.1043-B5			
4PP280.1043-75			
4PP280.1043-B5			
4PP280.1043-K02			
4PP281.1043-75			
4PP281.1043-B5			
4PP282.1043-75			
4PP282.1043-B5			
4PP28X.1043			
4PP250.1214-K01			
4PP220.1505-75			
4PP220.1505-B5			
4PP220.1505-K03			
4PP251.1505-75			
4PP251.1505-B5			
4PP280.1505-75			
4PP280.1505-B5			
4PP281.1505-75			
4PP281.1505-B5			
Power Panel 300			
4PP320.0571-01	LCD,	New & Replacement	Available

Repair Parts for B&R HMI

4PP320.0571-35	Shell,		
5PP320.0571-29	Touch Glass		
5PP320.0571-39			
5PP320.0571-K02			
5PP320.0573-39			
5PP320.0573-3B			
5PP320.0571-K17			
5PP320.0571-K05			
5PP320.0571-K06			
5PP320.0571-K10			
5PP320.0571-K11			
5PP320.0571-K12			
5PP320.0571-K14			
4PP320.0653-K01			
5PP320.0653-K02			
5PP320.0653-K03			
4PP380.0844-K01			
4PP320.1043-31			
4PP320.1043-75			
4PP320.1043-85			
5PP320.1043-39			
5PP320.1043-K0			
4PP320.1043-K06			

Repair Parts for B&R HMI

4PP320.1043-K11

5PP320.1043-K18

5PP320.1044-K04

5PP320.1043-K04

5PP320.1043-K07

5PP320.1043-K10

5PP320.1043-K12

5PP320.1043-K14

5PP320.1043-K16

4PP381.1043-31

5PP320.1214-39

5PP320.1214-K09

4PP320.1505-31

5PP320.1505-39

5PP320.1505-K05

5PP320.1505-3B

5PP320.1505-K04

5PP320.1505-K15

4PP320.1505-K01

5PP320.1505-K10

5PP320.1505-K14

4PP352.0571-35

4PP351.0571-35

Repair Parts for B&R HMI

4PP351.0571-01			
3PP381.1043-31			
Power Panel 400			
4PP420.0571-45	LCD,	New & Replacement	Available
4PP420.0571-65	Shell,		
4PP420.0571-75	Touch Glass		
4PP420.0571-85			
4PP420.0571-A5			
4PP420.0571-B5			
4PP420.0571-K02			
4PP420.0571-K04			
4PP420.0571-K05			
4PP420.0571-K06			
4PP420.0571-K14			
4PP420.0571-K15			
4PP420.0571-K22			
4PP420.0571-K23			
4PP420.0571-K30			
4PP420.0571-K40			
4PP420.0571-K44			
4PP420.0571-K45			
4PP420.0571-K46			
4PP420.0571-K47			

Repair Parts for B&R HMI

4PP420.0571-K49

4PP420.0573-75

4PP420.0844-K03

4PP420.1043-75

4PP420.1043-B5

4PP420.1043-K02

4PP420.1043-K07

4PP420.1043-K08

4PP420.1043-K14

4PP420.1043-K24

4PP420.1043-K35

4PP420.1043-K37

4PP420.1043-K40

4PP420.1043-K41

4PP420.1043-K45

4PP420.1043-K49

4PP420.1043-K53

4PP420.1043-K59

4PP420.1043-K60

4PP420.1043-K63

4PP420.1505-75

4PP420.1505-B5

4PP420.1505-K04

Repair Parts for B&R HMI

4PP420.1505-K05

4PP450.0571-K13

4PP450.0571-K25

4PP450.0571-K28

4PP450.1043-K01

4PP450.1043-K05

4PP451.0571-45

4PP451.0571-65

4PP451.0571-75

4PP451.0571-85

4PP451.0571-B5

4PP451.1043.85

4PP451.1043-75

4PP452.1043-75

4PP480.1043-73

4PP480.1043-75

4PP480.1043-K03

4PP480.1043-K04

4PP480.1043-K05

4PP480.1043-K06

4PP480.1043-K09

4PP480.1505-75

4PP480.1505-B5

Repair Parts for B&R HMI

4PP480.1505-K02			
4PP481.1043.85			
4PP481.1043-75			
4PP481.1043-B5			
4PP481.1505-75			
4PP482.1043-75			
5PP420.1044-K02			
Power Panel 500			
5PP520.0573-00	LCD,	New & Replacement	Available
5PP520.0573-01	Shell,		
5PP520.0573-B00	Touch Glass		
5PP520.0573-B01			
5PP520.0573-B10			
5PP520.0573-B11			
5PP551.0573-00			
5PP552.0573-00			
5PP520.0702-00			
5PP520.0702-K01			
5PP520.0702-B00			
5PP520.0702-K06			
5PP520.0702-K08			
5PP520.0702-B10			
5PP580.0844-K01			

Repair Parts for B&R HMI

5PP520.1043-00

5PP520.1043-K23

5PP520.1043-K06

5PP520.1043-B00

5PP520.1043-B10

5PP520.1043-B50

5PP520.1043-K12

5PP580.1043-00

5PP581.1043-00

5PP582.1043-00

5PP520.1214-00

5PP520.1214-K01

5PP520.1214-K04

5PP520.1505-00

5PP520.1505-K03

5PP520.1505-P00

5PP520.1505-S00

5PP520.1505-K01

5PP520.1505-B00

5PP520.1505-B10

5PP520.1505-B50

5PP520.1505-B55

5PP520.1505-B60

Repair Parts for B&R HMI

5PP520.1505-B65

5PP580.1505-00

5PP580.1505-K01

5PP581.1505-00

5PP5:463148.001-00

5PP5:206114.002-00

5PP5:404380.002-00

5PP5:436504.001-02

5PP5:405667.001-00

5PP5:212440.000-03

5PP5:220641.001-00

5PP5:240252.000-00

5PP5:404317.000-00

5PP5:439456.003-00

5PP5:462629.003-00

5PP5:220340.000-02

5PP5:220377.067-00

5PP5:405871.001-01

661969-000 SCN-AT

(E274) 002741HL-586

FLT09.4-002

5PP5:449599.000-00

T0282-45 T0282-45 A

Repair Parts for B&R HMI

5PP5:401.1233.00			
Power Panel 900			
5AP920.1043-01	LCD,	New & Replacement	Available
5AP920.1043-K01	Shell,		
5AP920.1043-K02	Touch Glass		
5AP920.1043-K04			
5AP920.1043-K09			
5AP951.1043-01			
5AP952.1043-01			
5AP980.1043-01			
5AP981.1043-01			
5AP982.1043-01			
5AP920.1214-01			
5AP920.1214-K01			
5AP920.1214-K04			
5AP920.1214-K06			
5AP923.1215-I00			
5AP980.1214-K03			
5AP980.1214-K04			
5AP920.1505-01			
5AP920.1505-K04			
5AP920.1505-K06			
5AP920.1505-K08			

Repair Parts for B&R HMI

5AP920.1505-K09

5AP920.1505-K10

5AP920.1505-K11

5AP920.1505-K16

5AP920.1505-K19

5AP920.1505-K20

5AP920.1505-K21

5AP920.1505-K23

5AP920.1505-K24

5AP920.1505-K26

5AP920.1505-K28

5AP920.1505-K32

5AP920.1505-K34

5AP920.1505-K38

5AP920.1505-K42

5AP920.1505-K43

5AP920.1505-K54

5AP920.1505-K55

5AP920.1505-K59

5AP920.1505-K63

5AP920.1505-K64

5AP920.1505-K65

5AP920.1505-K69

Repair Parts for B&R HMI

5AP920.1505-K70

5AP920.1505-K71

5AP920.1505-K74

5AP920.1505-K75

5AP920.1505-K89

5AP920.1505-K94

5AP920.1505-K96

5AP920.1505-K98

5AP920.1505-KA0

5AP920.1505-KA2

5AP920.1505-KB0

5AP923.1505-K04

5AP92D.1505-00

5AP92D.1505-01

5AP950.1505-K05

5AP951.1505-01

5AP980.1505-01

5AP980.1505-B10

5AP980.1505-K01

5AP980.1505-K08

5AP980.1505-K09

5AP980.1505-K11

5AP980.1505-K30

Repair Parts for B&R HMI

5AP980.1505-K31

5AP981.1505-01

5AP920.1706-01

5AP920.1706-K01

5AP980.1706-K02

5AP920.1906-01

5AP920.1906-K02

5AP920.1906-K03

5AP920.1906-K07

5AP920.1906-K09

5AP920.1906-K14

5AP920.1906-K20

5AP920.1906-K24

5AP920.1906-K27

5AP920.1906-K28

5AP920.1906-K29

5AP920.1906-K34

5AP92D.1906-00

5AP92D.1906-01

5AP980.1906-K01

5AP920.2138-01

5AP93D.215C-K01

5AP980.215C-K02

Repair Parts for B&R HMI

<p>5Z5ZC220Z07031-003</p> <p>5P62:BEST720-60</p> <p>5P62:BEST720-10</p> <p>5P62:JENSEN-SEN-03</p> <p>5P62:JENSEN-SEN-08</p> <p>5P62:BEST720-30</p> <p>5P62:KHS-07</p>			
<h3>PanelWare</h3>			
<p>4B1210.00-590</p> <p>4B1250.00-490</p> <p>4B1260.00-390</p> <p>4B1260.00-490</p> <p>4B1270.00-390</p> <p>4B1270.00-490</p> <p>4B1270.00-K09</p> <p>4B1270.00-K15</p> <p>4B1270.00-K18</p> <p>4B1384.00-K07</p> <p>4B1384.00-K08</p> <p>4B1384.00-K14</p> <p>4B1384.00-K16</p> <p>4D1165.00-490</p> <p>4D1165.00-K05</p>	<p>LCD,</p> <p>Shell,</p> <p>Touch Glass</p>	<p>New & Replacement</p>	<p>Available</p>

Repair Parts for B&R HMI

4D1165.00-K08			
4D1166.00-490			
4D1167.00-490			
4PW035.E300-01			
4PW035.E300-02			
Mobile Panel			
5MP040.0381-01	LCD,	New & Replacement	Available
5MP040.0381-02	Shell,		
5MP050.0653-01	Touch Glass		
5MP050.0653-02			
5MP050.0653-03			
5MP050.0653-04			
5MP050.0653-K01			
5MP050.0653-K03			
4MP181.0843-03			
4MP181.0843-K04			
5MP181.0843-07			
5MP181.0843-K01			
5MP181.0843-K04			
5MP181.0843-K05			
4MP251.0571-12			
4MP251.0571-K02			
4MP281.0571-12			

Repair Parts for B&R HMI

4MP281.0571-K01			
4MP281.0843-13			
4MP281.0843-K03			
4MP281.0843-K04			
5MP7120.034F-000			
5MP7121.034F-000			
5MP7140.070N-000			
5MP7150.101E-000			
5MP7151.101E-000			
5MP7151.101E-001			
IPC Panel			
5AP1120.0573-000	LCD,	New & Replacement	Available
5AP1151.0573-000	Shell,		
5AP1120.0702-000	Touch Glass		
5AP1120.0702-I00			
5AP1120.101E-000			
5AP1120.1043-000			
5AP1120.1043-C01			
5AP1120.1043-C04			
5AP1120.1044-C02			
5AP1125.1043-I00			
5AP1125.1044-I00			
5AP1180.1043-000			

Repair Parts for B&R HMI

5AP1181.1043-000

5AP1182.1043-000

5AP1120.1214-000

5AP1120.1215-C02

5AP1120.121E-000

5AP1120.1505-000

5AP1120.1505-C01

5AP1120.156B-000

5AP1125.1505-I00

5AP1180.1505-000

5AP1120.1906-000

5AP5120.1505-000

5AP5120.1906-000

5AP520.1505-K10

5AP520.1706-01

5AP820.1505-00

5AP820.1505-10

5AP880.1505-00

5AP880.1505-10

5AP923.1215-00

5AP923.1505-00

5AP923.1505-I00

5AP923.1505-I01

Repair Parts for B&R HMI

5PP920.1505-K15			
5PP920.1505-K16			
5PP920.1505-K40			
5PP920.1505-K42			
5AP923.1906-00			
5PC725.1505-K03			
Provit Panel			
5A2500.08	LCD,	New & Replacement	Available
5A2500.09	Shell,		
5C2002.02	Touch Glass		
5D2000.02			
5D2200.01			
5D2200.02			
5D2200.04			
5D2200.07			
5D2200.10			
5D2200.17			
5D2210.01			
5D2219.01			
5D2219.02			
5D2219.03			
5D2300.01			
5D2300.02			

Repair Parts for B&R HMI

5D2300.03

5D2500.01

5D2500.02

5D2500.10

5D2500.22

5D2500.36

5D2500.41

5D2500.47

5D2510.01

5D2510.10

5D2510.22

5D2519.01

5D2519.02

5D2519.08

5D5200.01

5D520001

5D5201.02

5D5210.01

5D5211.02

5D5500.10

5D5500.32

5D5501.01

5D5510.10

Repair Parts for B&R HMI

5D5600.01

5D5600.02

5D5600.03

5D5201.03

5D5211.03

5D5601.01 Rev.K0

5D5601.02

5D5601.03

5D5200.04

5D5202.01

5D5202.03

5D5212.01

5D5202.05

5D5212.02

5D5212.04

5D5212.26

5D5213.01

5D5213.02

5D5501.20

5D9200.01

5D5200.13

5D5200.33

5D5200.35

Repair Parts for B&R HMI

5D5201.11			
5D5212.20			
5D5212.24			
5D5500.59			
5D5501.07			
5D5600.06			
5D2200.07			
5D2200.10			
5D2210.01			

Please go the official website of SEAWENS to find more details, photos and instructions of all the products !

Seawens Technology Co., Limited.

YuHui Electronic Commerce co.,Ltd

Add: Daya Bay West District Street, No. 333 Shihua Avenue West, Huizhou City, Guangdong

Province, China

PC: 516000

Web: <https://www.seawens.com>

Phone: +86-185 6588 9964

Shop: <https://www.ia-mall.com>

E-mail: sales@seawens.com